Aluminum PC Case Installation Guide

Case components:





Support liquid cooling system



Loosen the screws to remove dust-free cover for water tube openings.

Side panels installation



Loose the screw and pull the latch to release the side panel.



Remove the side panel.



Adding a lock to secure the hardware.

Remove mounting bracket



Removable air filter

Push to release

Chip set cooler installation



Rubber protectors for aluminum wheels.



Removable fan filter



Removable air filter

Loosing the two thumb screws on the fan module to release.

Hard disk installation



1. Fasten the HDD screws with anti-vibration rubber rings to the HDD.



2. Slide the HDD into the HDD cage with the anti-vibration kit.



3. Press down the HDD into the slots to secure.



Note:
Adding extra screw to the HDD cage for extra security.

Hardware list

＊ Extra quantities are spare parts.

Buzzer(1)	Screw(70 to fix drive & motherboard	Thumb screw(34) & rubber ring(34) for fix HDD	Chip set cooler(1)+ themb screw(2) to mount on PCI card holder
Extension cable 12V(1) for power supply to M/B	Stand off bolt(16) for motherboard		
Power supply holder kit(2)	Intel noconaXeon(1) for SSI CEB/EEB	Nut(3) for stand off	Rubber protectors(4) for wheels
PCI card holder-S(3)	Screw driver(1) for stand off bolt	Thumb screw(1) spare part	For user who wants to use single power supply unit, and using the space next to it for other purpose.
PCI card holder-L(4)	Thumb screw(8) for HDD extra fixing	Cable tie(3)	
Thumb screw(7) for PCI card holder	Screw (8) to fix power supply	Clamp(2) for cable management	Box(1) for spare parts
Mounting plate for dual PSUs, Recommended to use the power supply with 80mm exhaust fan.			

Motherboard installation





Loosing two thumb screws to release the M/B tray.


Motherboard
for SSI CEB/EEB
The oval hole on M/B tray designed for special server boards, please use the nut to hold the copper bolt in place.

Secure the stand off bolts on the M/B tray which match with the M/B fix points, place the M/B on the copper bolt, fasten the screws to secure.

3-speed fan adjustable device



Release brake

PSU tray installation















Mounting plate for dual PSUs, Recommended to use the power supply with 80mm exhaust fan.



Extension cable for 12V PSU to M/B



For user who wants to use single power supply unit, and using the space next to it for other purpose.



Loosing two screws on the case bottom to release long power supply support bracket.



Fasten the screws on the case bottom to secure the power bracket.

VGA Card Pillar Installation Guide









I/O Port installation